



# ITT Industries

Engineered Process Solutions Group

33 CENTERVILLE ROAD  
LANCASTER PA 17603-2064

TEL: (717) 509-2200

FAX: (717) 509-2336

## **INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS**

**MODEL T4155C & T4156C**

**Skotch<sup>®</sup> Trifecta<sup>®</sup> GAS VALVE SYSTEM**

### **WARNING**

**Valves and valve actuators supplied by Engineered Process Solutions Group are designed and manufactured using good workmanship and materials, and they meet the applicable industry standards. These valves are available with components of various materials, and they should be used only in services recommended herein or by a company valve engineer. Misapplication of the product may result in injuries or property damage. A selection of valve components of the proper material consistent with the particular performance requirement, is important for proper application.**

**Examples of the misapplication or misuse of a valve or valve actuator includes use in an application that exceeds the pressure/temperature rating, or failure to maintain the equipment as recommended.**

**Technical Manual No. IOT4150C**

**Effective 7/21/03**

**REV LEVEL -**  
*Printed August 29, 2003*

## Record of Revisions

Revision	Description	Date
-	First Issue <i>K. Atorpe</i>	07/21/03

**FILE COPY**

Technical Manual No. IOT4150C

Effective 7/21/03

REV LEVEL -  
*Printed July 21, 2003*


# TABLE OF CONTENTS


SECTION		PAGE
I.	Description .....	4
II.	Operation .....	5
III.	Installation .....	7
IV.	Commissioning .....	10
V.	Disassembly/Rebuilding/Maintenance Instructions .....	10
VI.	Leak Testing .....	19
VII.	Proof of Closure Switch Testing .....	20
VIII.	Miscellaneous Instructions for Special Options .....	21
IX.	Spare Parts Ordering Information .....	22
X.	Reference Information .....	22

## DRAWINGS

118967	Valve Assembly - Model T4150C Systems
119122	Valve and Actuator Assembly
119016	POC Assembly (Optional)
119430	Wiring Diagram AC Solenoid
119431	Wiring Diagram DC Solenoid
119429	Pneumatic Schematic - Fail Closed
117624	Pneumatic Schematic – Fail In Last Position

## SAFETY NOTE:

	<p><b>The safety precautions in these operating instructions are specially marked with the standard symbol for danger when non-observance could result in personal injury, loss of life or property damage.</b></p>
---	---

	<p><b>Non-observance of these safety precautions can endanger the valve and its functions.</b></p>
---	--

**I. DESCRIPTION**

The Model T4150C Skotch® Burner Valve System provides all the isolation and venting functions necessary for automated operation of gas-fired burners in utility and industrial power plants. This includes double block of the main gas line and venting the chamber between blocks to atmosphere. Hence, the term "Double Block and Vent" or "Double Block and Bleed". The vents are sized in accordance to IRI's (Industrial Risk Insurers) and NFPA (National Fire Protections Association) recommended vent sizes. To satisfy code requirements, a Proof of Closure (POC) switch utilizing valve seal overtravel is supplied as standard to prove the valve is closed. Optional switches to monitor valve open position and a second Proof of Closure (POC) can offer added feedback for plant DCS systems.

The Model T4155C valve system, which is the Fail-in-Last Position model, utilizes a dual coil momentary contact pilot solenoid for pneumatic operation and requires compressed air and electric power to open and close. The system fails in the last position on loss of pneumatic or electric power. It will not hold this position indefinitely if air is lost.

Due to the failure mode, Model T4155C valve systems can never be Factory Mutual (FM) approved.

The Model T4156C valve system, which is the Fail Closed model, utilizes a single coil maintain contact spring return pilot solenoid for pneumatic operation and requires compressed air and electric power to open. The system closes on a loss of pneumatic or electric power.

Model T4156C valves incorporating specific configurations may be Factory Mutual approved for Natural Gas Safety Shutoff Valves per FM Approval Standard Class 7400. Valves configured for FM Approval are tagged as such.

**II. OPERATION**

Refer to solenoid assembly nameplate or purchase order specifications to determine appropriate line voltage and type. Operation is in accordance with referenced drawings.

**A. *Open Block Valves (Close Vent)***

Both T4155C and T4156C valves follow similar opening protocol.

With pneumatic supply pressure regulated to a minimum of 60 psig and a maximum of 120 psig, apply line voltage across terminal points 1 and 2. This energizes the pilot solenoid, allowing pneumatic pressure into the cylinder.

As pressure is admitted to the cylinder, the outlet valve return spring is compressed and the outlet valve plug moves out of its seat ring. Concurrently, the vent valve moves into its seat until first the soft seal and then a metal to metal backup seal is made closing the vent.


Upon vent closure, the piston continues to stroke. This pushes the inlet valve plug out of its seat ring, compressing the inlet valve return spring. Stroking stops when the actuator piston contacts a travel stop internal to the actuator. Flow commences only after the inlet plug clears its seat. Thus, no flow occurs until the vent is closed.

**B. *Close Block Valves (Open Vent)***

How the valve is commanded Closed differs for the two model numbers.

For T4155C valves:

Deleting voltage from terminals 1 and 2 and applying voltage to terminals 1 and 3 of the pilot solenoid exhausts pneumatic pressure from the cylinder.

	<p><b>Note: Never energize both solenoid coils simultaneously. Doing so, will permanently damage the coils.</b></p>
---	---

For T4156C valves:

Deleting voltage from terminals 1 and 2 de-energizes the pilot solenoid and exhausts pneumatic pressure from the cylinder.

For both models:

Upon exhausting the cylinder, both inlet and actuator return spring (for outlet) move their respective plugs toward their seat rings. First the inlet valve soft seal makes, halting gas flow through the assembly, then its metal back-up. Next the vent moves off its seat, opening the vent and relieving downstream pressure. Finally, the outlet valve soft seal, followed by its metal back-up close, completing the cycle. Two independent blocks are formed between system inlet and outlet, with the chamber between the block valves ported to vent. The POC switch trips after the outlet valve soft seal starts into its seat.

**C. Notes**

For Model T4155C valves, the solenoid pilot valve is a dual coil momentary contact type, rated for continuous duty at the service voltage.


For Model T4156C valves, the solenoid pilot valve is a maintained contact type, rated for continuous duty at the service voltage.

A proof of closure (POC) switch is provided as standard for the outlet valve. The outlet valve POC is mounted to the side of the actuator yoke, just above the top of the valve. Logic is shown on the referenced wiring diagram. Some valves may be equipped with an optional open limit switch (mounted parallel to the outlet valve POC), and/or a second POC switch for the inlet, mounted to the special bracket on the bottom of the valve.

### III. INSTALLATION

#### A. *Unpacking*


- Leave protective plastic plugs (in valve orifices) in place until ready to install.
- Only lift the valve using proper hoisting procedures; if using a sling, place it around the valve body.

	<p><b>Note: Valve weighs over 110 lb in base form. Use proper moving safety precautions for transporting the valve. Do not place the sling around the actuator, as damage can occur to the valve system.</b></p>
---	--


- Check valve to make sure all Warning and Visual Position Indication labels have remained properly adhered during shipping.
- If shipping packaging has been damaged, check for any signs of damage to the valve/actuation system. Consult factory if there is any signs of suspected damage.

**B. Valve Installation**

- Verify no debris or foreign objects are inside the valve.
- Purge the gas line prior to installing the valve.

	<p><b>Prior to installation and/or start-up, piping should be verified as being free of dirt, grit, welding slag, or other particulate contamination. Failure to do so may result in damage to valve internals.</b></p>
---	---


- Verify proper pipe connections are available for the valve. Proper vent pipe sizing per NFPA 85 needs to be verified. The T4150C Skotch Trifecta Valve System is typically supplied with a female NPT vent connection and spigot inlet and outlet connections. (Note: Other end configurations available upon request.) Refer to order specification or purchase order specifications for type supplied. Valve installation should be in accordance with standard practices for end connection provided. Flanges are raised face carbon steel per ANSI B16.5. Threads are per ANSI B2.1. Ensure the weight of the system is properly supported to prevent excessive stresses. (*Piping supports should be designed for a base valve weight slightly exceeding 110 lb – options can add to this weight*). Valve may be installed in any orientation. Ensure flow direction is appropriate for intended installation. Valves incorporating welded ends should follow special precaution to insure weld heat does not damage the valve seals and gaskets. Temperatures in these areas should be kept below 200° F.

	<p><b>Vent pipe size should be equivalent to the vent fitting size supplied. Reducing vent size may result in insufficient flow capacity. Under NO circumstance should the vent be blocked or plugged.</b></p>
---	--

**C. Pneumatic/Electrical Hook Up**

Utilities required for operation are electrical power and clean dry compressed air. Wiring should be in accordance with referenced drawings and all applicable codes. Supply air should be filtered to 40 microns minimum and connected per referenced drawing.


- Purge all air lines prior to connecting solenoids.

	<b>Historically many problems at start-up are due to mishandling of the valve and poor purging of the fuel and pneumatic control lines.</b>
---	---

- Assure that pneumatic air supply to solenoid does not exceed 120 psig. A filtered, regulated supply air pressure between 60 and 120 psig needs to be provided for the valve for proper operation.

	<b>Failure to maintain proper pneumatic air line pressure could result in damage to the valve.</b>
---	--

- Use suitable thread sealing compound only. Do not use PTFE tape.

	<b><i>The exhaust side of the solenoid should not be restricted. This will slow the closing rate of the valve. Valve is supplied with an appropriate exhausting muffler that ensures proper closing rate. Please consult the factory for any solenoid replacement parts.</i></b>
---	--

Note: Some assemblies may include a filter regulator (Optional).

**IV. COMMISSIONING**


- Confirm that all valve connections have no leaks within appropriate pressure ranges.
- Confirm that upstream gas pressure has been properly regulated at or below valve maximum rated line pressure.
- Confirm that valve strokes properly when solenoid is energized, and that the visual indicator and switch/s are indicating correctly.
- Confirm that the valve strokes closed completely, and that visual indicator and switch/s are indicating as such.
- Confirm that the valve is properly supported.
- Confirm that the solenoid voltage is +0%, - 15% of pilot solenoid tag rating for continuous duty requirements.
- Verify that the valve has proper clearances top and bottom for any (in-line) disassembly needs in the future.

**V. DISASSEMBLY AND MAINTENANCE INSTRUCTIONS**

All T4150C Valve Systems may be completely disassembled without removal from the piping. However, it is recommended that it be rebuilt in a shop with suitable fixturing, hoisting equipment and tools.

**NOTE:** Customers that do not feel comfortable with rebuilding and testing Skotch valves can have them rebuilt by the factory. Call the number located on the front cover or (800) 366-1111 and ask to speak to Skotch, Customer Service for quotation and instructions.

Refer to the Valve Assembly, and Valve Actuator Assembly drawings listed above. Item numbers, (x), refer to referenced drawings.

	<p><b>Ensure all manual isolation valves are closed and tagged out, all electrical circuits are de-energized and that the pneumatic supply and valve are isolated and depressurized before performing any work on the valves.</b></p>
---	---

**IMPORTANT:** Special tools are needed for disassembly and assembly. They should be procured before work begins.

Special tools include:

- ITT P/N: 43029, Tool Seat Ring Wrench T4150C. Needed to remove the seat from the body.
- ITT P/N: 43030, Tool Seal Assembly Tool T4150C. Needed to replace the inlet & outlet soft seals.
- ITT P/N: 43031, Tool Seal Protector T4150C. Needed during installation of outlet valve stem.
- ITT P/N: 43032, Tool Actuator Disassembly. Needed to safely disassemble/assemble actuator that is under compression spring pressure.

**A. *Disassembly***

A clean dry area should be provided for valve disassembly.

**1) Detach Actuation Assembly (reference drawing 119122)**

Remove four screws (78) to remove lens cover (77). Set aside.


Loosen coupler set screw (57), and remove trip bracket (62) and hardware (63), (64), (65). Set aside trip bracket & mounting hardware. Unthread coupler (56) while holding valve stem with wrench. Care should be taken not to allow the stem to rotate. Allow the coupler to drop down on the attachment nut. Item (53) will be loose when removing coupler, set loose washer aside. While holding valve stem with a wrench, remove spherical nut (52) – this has a small amount of

retaining Loctite on the threads.

Using a punch and hammer, loosen attachment nut (51), unthread until completely loose.

Carefully pull the Yoke/Actuator subassembly up off the top of the valve. Set aside the attachment nut (51) and coupler (56). Examine the coupler washer (54) for wear around the ID. Replace if more than 0.010” has been worn away.

If rebuilding the actuator (59), please consult the factory to purchase the appropriate rebuild kit, and Actuator Disassembly Tool (P/N 43032). Instructions for rebuilding the actuator are contained in the rebuild kit. Unthread and remove coupler adapter (55), jam nut (58), and actuator stud nuts (60), lock washers (61), to remove actuator.

	<p><b>The actuator (as labeled) is under spring compression. Under no conditions should user disassemble actuator without appropriate tool from ITT. Failure to comply could result in bodily injury or death.</b></p>
---	--

**2) Valve Disassembly (reference drawing 118967)**

Unscrew the vent flange (32) from the body using a strap wrench. Remove o-ring (13), thrust washer (10), and vent shaft seal (11). Care should be taken when vent located on bottom as spring and inlet block subassembly can come out along with vent connection). Return spring (5) and inlet valve subassembly must drop out with the vent flange.

Remove return spring (5) and the inlet valve subassembly. Using seal assembly tool (P/N 43030) and appropriate adjustable wrench, disassemble the inlet disk (8) from the vent cap (7). Medium grade Loctite is used to retain the threads. Remove the inlet seal (9).

Reaching into the valve body, carefully slide the outlet valve subassembly out of the valve body. Using seal assembly tool (P/N 43030) and appropriate adjustable wrench, disassemble the outlet plug (19) from the outlet stem (22). Medium grade Loctite is used to retain the threads. Remove the outlet seal retaining washer (21) and outlet seal (20).

Remove vent seal capscrew (14), retaining washer (15). Slide off the vent seal retainer (17) and vent seal (16). Also slide off vent spring (18). Note: vent seal capscrew has a small amount of medium grade Loctite to retain threads.

Inspect the seat ring (3) for any signs of scratches, voids in the sealing area. Remove for replacement as necessary using seat ring wrench (P/N 43029). Remove seat ring o-ring (4). Note: vent seal capscrew has a small amount of medium grade Loctite to retain threads.

Remove four cap screws (30) in top flange (23) and slide top flange out of valve body. Remove o-ring (31), and using snap ring pliers, remove retaining ring (24). Slide out flat washer (25), and stem u-cup seal (26). The valve is now fully disassembled.

### **3) Disassembly of Valve with Second POC Switch (reference drawing 119016)**

Before beginning Section 2) above, loosen set screw (113) and allow switch Actuator (112) to drop loose. Using a punch and hammer loosen attachment nut (111) closest to body, and unthread. Drop the entire POC subassembly off the vent shaft.

Using snap ring pliers, remove retaining ring (121). Slide out flat washer (122), and stem u-cup seal (123) from the bottom POC flange (120). Remove the wiper seal (130) from the vent flange (32).

See Section 2) above for the remainder of the valve disassembly.

#### ***B. Valve Rebuilding***

Reference the same drawings as above. For the most part, rebuilding will follow a reverse order of the above instructions. For rebuild kits, please contact the factory. Rebuild kits will include usual soft seal type parts. Metal components must be ordered separately.

##### **1) Discarded components:**

Seat ring o-ring (4)  
Inlet seal (9)

Vent shaft seal u-cup (11)  
Vent flange o-ring (13)  
Vent seal (16)  
Vent spring (18)  
Outlet seal (20)  
Outlet stem seal u-cup (26)  
Top flange o-ring (31)  
POC Bottom flange seal u-cup (123)  
POC vent flange wiper seal (130)

**2) Components to Inspect:**

Inlet disk (8), and outlet plug (19) have metal-metal seating rounded surfaces. Inspect radius surfaces for wear or score marks. Replace as required.

Seat ring (3), and cap vent (7) have internal chamfer surfaces for metal-metal seating. Inspect chamfer surface for wear, voids, deep scratches. Replace as required.

Inspect vent shaft (6) and outlet stem (22) outside diameters for heavy wear in the u-cup sealing areas. Wear that one can catch his finger on indicates replacement is necessary. Check bearing IDs for wear, and replace flange subassemblies as required.

As mentioned above, examine the coupler washer (54) for wear around the ID. Replace if more than 0.010" has been worn away.

**3) Valve Reassembly ( reference drawing 119024)**

Clean all re-usable metal components with good quality solvent. Wire brush any threaded joints that were locked with Loctite.

Apply primer and Loctite 242 to threads on the seat ring (3). Apply a small amount of o-ring lube (such as Dow Corning 55) to the seat ring o-ring seal (4), and set in position shown on drawing on the seat ring (3). Carefully hand thread the seat ring subassembly into the body (1). Monitor o-ring position on the seat ring as it is threading in. If the o-ring moves out of the step on the seat ring while threading it in, reposition the o-ring, as damage may occur to the seal, and it will not provide the necessary seal.

Reassemble inlet valve subassembly by applying small amount of o-ring lube to inlet seal (9) mating surfaces. Set the seal in position on the inlet disk (8), apply primer and Loctite 242 to threads on cap vent (7). Using seal assembly tool (P/N 43030), thread inlet disk (8) & seal (9) onto the cap vent (7).

NOTE: thread the inlet disk until it stops on metal shoulder of the cap vent. You will feel the metal-metal stop as it is threading.

Reassemble the outlet valve subassembly by applying small amount of o-ring lube to the outlet seal (20) mating surfaces. Set the seal in position on the outlet plug (19). Lay seal retainer washer (21) on top of seal (20), align center hole. Apply primer and Loctite 242 to the threads of the outlet stem (22), and thread into plug using the seal assembly tool (P/N 43030) and wrench (on the outlet stem). As with inlet assembly above, thread the stem in until the retainer washer (21) has met the metal shoulder on the plug (19). You will feel the metal-metal stop while threading.

Turn over the subassembly. Slide the wave spring (18) down over the boss on the outlet plug (19). Slide the vent washer retainer (17) on next, now in contact with wave spring (18). Lay the vent seal (16) into the well of the washer retainer (17). Make sure that the vent seal (16) does not sit outside the side walls of the retaining feature of the washer retainer. Subassemble the vent seal retainer (15) onto the capscrew (14), apply primer and Loctite 242 to the threads of the capscrew, and thread into the threaded hole on the boss of the outlet plug (19). Care must be taken not to pinch the vent seal (16). Capscrew should thread into outlet plug (19) & vent seal (16) expanded. Capscrew should thread into outlet plug until the vent seal retainer (15) stops metal-metal with the end of the boss on the outlet plug (19). The outlet subassembly is now ready for final assembly.

Subassemble the top flange. Apply a small amount of o-ring lube to a new outlet stem u-cup seal (26) and insert into the top flange (23) as shown on drawing (U-cup opening to pressure side). Drop in the flat washer (25), and hold in place with the snap ring (24). Make sure the snap ring is correctly in position, and holds the subassembly together. Apply a small amount of o-ring lube to a new top flange o-ring seal (31). Assemble the o-ring (31) into its groove on the top flange (23). The top flange subassembly is now ready for final assembly.

Thread the protective sleeve (P/N 43031) onto the threaded end of the outlet stem (22). Set the top flange subassembly into the body (1) as shown on the

drawing, care must be taken to not damage the o-ring seal. Place anti-sieze on the threads of the four top flange capscrews (30). Thread capscrews (30) into top flange with torque wrench set to 15 ft-lb. Torque in a criss-cross pattern. Re-torque to 25 ft-lb. in a criss-cross pattern.

Insert the outlet valve subassembly, stem first, into the valve body (1), and up through the top flange subassembly. Care must be taken when inserting the protective sleeve through the stem seal (26). Seat the assembly until the plug (19) goes metal-metal with the seat ring (3).

Insert the inlet block assembly into the valve body (1) as shown on the drawing (seal end first) until the cap vent goes metal-metal with the seat ring (3). Slide the return spring (5) down over vent shaft (6), and place thrust washer (10) on top of spring. Apply a small amount of o-ring lube to a new vent shaft u-cup seal (11), and insert the u-cup onto the vent shaft (6) in direction as shown on the drawing (U-cup opening to pressure side). Apply a small amount of o-ring lube to a new vent flange o-ring seal (13), and set in position the body (1) as shown on the drawing. Prepare the vent flange (32) by applying a small amount of anti-sieze on the threads. Align the vent shaft (6) with the bearing in the vent flange (32), and begin to hand thread the vent flange into the body (1). Continue vent flange threading with a strap wrench until metal-metal tight with the body (1). Assure that the o-ring did not get cut during the threading operation. Valve assembly is now complete.

#### **4) Valve – Actuation Assembly (reference drawing 119122)**

Lubricate the surface of the coupler washer (54) and bottom ID of the coupler (56) with appropriate lube. Place the washer (54) into position in the coupler (56) as shown in the drawing. Place yoke (50) with actuator (59) attached down over valve stem (22). Slide the attachment nut (51) down over valve stem, as well as the coupler subassembly from above. Thread on the attachment nut (51) to the top flange (23). Align yoke (50), lock in place with a punch and hammer. Assure that the yoke (50) does not rotate on the top flange when assembly is complete. Apply primer and a small amount of Loctite 242 to the valve stem threads (22). Thread on spherical nut (52) using appropriate wrenches to keep stem from rotating.

Lubricate the top surface of the spherical nut (52), and the spherical washer (53) with anti-sieze. Align all of the parts with the actuator stem/coupler adapter (55), and thread the coupler (56) by hand until it stops. Do not

overtighten yet. With both hands clear of the yoke (50), apply air into the actuator to stroke the valve. When stem motion has ceased, continue to thread coupler (56) at least one complete turn using only hand wrenches, then align trip bracket mounting holes with the side slot in the yoke (50) where the switches are mounted. (A total of one – two thread turns will be completed). Check to see if valve stem still has very slight free axial motion to permit alignment float of the stems. Remove air from actuator, and allow valve to close completely.



**Hands must be clear of the yoke box area before applying or relieving air to/from the actuator and moving the valve stem. Failure to comply could result in bodily injury.**

Lock the coupler (56) in position with set screw (57) as shown on the drawing. Attach the trip bracket (62) with mounting hardware (63) (64) (65). Attach lens (77) with screws (78). Valve-Actuator assembly is now complete. After reassembly, the valve and switches should be tested per the following procedures in Sections VI and VII.

**5) Re -assembly of Valve with Second POC Switch (reference drawing 119016)**

Apply o-ring lube to bottom flange u-cup seal (123), insert u-cup into bottom flange (120) as shown on drawing. Drop in flat washer (122), and secure in place with snap ring (121). Apply o-ring lube to vent flange wiper seal (130), and insert into vent flange (32) as shown on the drawing.

Start the POC subassembly up over the vent shaft (6) protruding from bottom of valve. Slide attachment nut (111) over vent shaft (6) once the bracket is started, and also slide the switch actuator onto the vent shaft as shown on drawing. Continue subassembling bracket to vent flange by threading on the attachment nut (111). Tight attachment nut with punch and hammer.

Preset the switch actuator close to where the switch trips at the very end of the closing stroke, and also allows the vent shaft to move when valve is opening to full open position. Tight set screw (113). After reassembly, the valve and switches should be tested per the following procedures in Sections VI and VII.

**C. Valve Maintenance****Periodic Inspection**

- ☑ Periodic leak testing of both block valves and verification of proper operation of proof of closure switch is recommended per the time schedule in the applicable codes. See Section VI for leak testing and Section VII for switch setting techniques.
- ☑ Inspect solenoid and actuator breather vents for foreign debris that can clog the breathing surfaces. Clean thoroughly or replace as required.
- ☑ Check for proper position and adhesion of the visual indicator label, and caution labels.
- ☑ Inspect switch trip brackets for straightness, that they are not bent, giving false readings.
- ☑ Ensure that the clear lens is attached. Re-install if missing.
- ☑ “Snoop” all sealing joints to make sure there are no external valve leaks.
- ☑ Check actuator supply air line for proper pressure settings (60 –120 psig)
- ☑ Check condition of all wiring/conduit and fittings for electrical components.

**Preventative Maintenance**

Valve soft seals should be replaced every 4 – 5 years **UNLESS** regular leak test inspections indicate earlier need. See Section VI for leak testing. See Section IX for information on ordering replacement parts for your Scotch Safety Shut-off Gas valve.

**VI. LEAK TESTING**

It is necessary to leak test each block valve and the vent valve individually to properly qualify the status of each seal. The valves are named in accordance to their position and function within the valve system.

**A. Inlet Valve**

1. Verify the valve is in the closed position.
2. Seal the outlet of the valve.
3. Pressurize inlet with 60 psig clean dry air while monitoring leak rate from the vent port. FM specifies a leak rate of 1 ft<sup>3</sup>/hr or less.

**B. Outlet Valve**

4. Verify the valve is in the closed position.
5. Seal the inlet side of the valve.
6. Pressurize the vent with 60 psig clean dry air while monitoring leak rate from the outlet. FM specifies a leak rate of 1 ft<sup>3</sup>/hr or less.

**C. Vent Valve**

1. Verify the valve is in the open position.
2. Seal the outlet port.
3. Pressurize the inlet with a maximum of 60 psig clean dry air, while monitoring the leak rate from the vent port. FM specifies a leak rate of 1 ft<sup>3</sup>/hr or less.

## **VII. PROOF OF CLOSURE SWITCH TESTING**

The T4150C valve system is provided with one proof of closure switch as standard. It can be provided with an optional open switch. The valves can also be provided with a second (inlet block) POC switch as well. Check the order specification for configuration provided.

The intent of the POC switch is to trip during valve seal overtravel of the valve block. Valve seal overtravel is the additional travel the valve strokes after flow stops. For reference FM defines the point of valve closure when flow  $< 1 \text{ ft}^3/\text{hr}$ . The switches should only change contact state when there is no flow. For example: When going from open to close, gas flow should stop and then the POC switch trip. Conversely, when going from closed to open the POC switch should change contact states prior to flow starting.

The POC switches should be tested after the valve has been leak tested.

### **1. Testing**

- a) Verify the valve is in the closed position and the normally closed contacts are made.
- b) Plug the inlet port. Stroke the valve very slowly until the switch trips. At this point, stop movement of the actuator and verify flow has not commenced ( $< 1 \text{ ft}^3/\text{hr}$ ) by pressurizing the vent port to 50 psig and measuring flow at the outlet. The actuator can be stroked slowly by regulating air pressure to the actuator.
- c) If there is evidence of flow prior to the POC switch tripping, the POC switch needs to be adjusted.

### **2. Setting**

- a) Loosen the roller switch lever (Item 67 or 102).
- b) Place an 0.100" shim between the switch actuator (Item 62 or 112) and the roller switch lever.

- c) While holding the roller firmly against the actuator shaft, rotate the switch actuator shaft until the normally closed contacts of the switch break. At this point securely fasten the lever to the switch actuator shaft.
- d) Remove the spacer. The roller switch lever should be firmly resting on the switch shaft and the normally closed contacts made.
- e) Check switch setting by stroking the valve to the open position. Pressurize the vent with 50 psig and monitor the flow at the outlet valve. If the switch trips before flow ceases, repeat but decrease shim thickness by 1/32". If the switch does not reset, increase the shim thickness by 1/32".

## **VIII. MISCELLANEOUS INSTRUCTIONS FOR SPECIAL OPTIONS**

Due to customer requirements, some T4150C Systems incorporate special options. Any special procedures not covered in the above material can be found in the Reference Section of this manual as addenda.

## **IX. SPARE PARTS ORDERING INFORMATION**

Orders for T4150C Valve Systems Spare Parts, rebuild kits, and tools should be placed with:

*ITT Industries  
Engineered Process Solutions Group  
33 Centerville Road  
Lancaster, PA 17603-2064*

*Phone: 717-509-2200  
Fax: 800-348-9000*

Please be advised that such items as solenoids and switches should not be ordered directly from their manufacturers as materials may be specially designed for Skotch Trifecta System service. Other replacement parts, although they may be similar in function, will void the FM rating. *To ensure FM rating and/or proper operation, replacement components should be purchased through ITT Engineered Process Solutions Group.*

## **X. REFERENCE INFORMATION**

The following pages contain drawings and reference information alluded to in above sections.